



# Nexus Omni

## Intersection Manager Installation Assistant

2602

## User Guide



**Legal Notice**

The company disclaims all liability and warranties in relation to this manual, including the warranties of merchantability, fitness for a particular purpose, and accuracy, and may amend it without further notice.

**Trademarks**

All trademarks or registered trademarks are the property of their respective owners.

**Contact Support (U.S. and Canada)**

- Email: [support@notraffic.tech](mailto:support@notraffic.tech)
- Toll-Free: 1-888-771-7879
- Direct: 1-202-800-1890

**Website**

- <https://notraffic.com>

Copyright © 2025 NoTraffic All Rights Reserved.

Nexus Omni Intersection Manager Installation Assistant 2602 User Guide Feb 04 2026

**Regulatory Compliance and Installation Requirements**

Product installation and qualification must be carried out in accordance with NoTraffic's instructions and in full compliance with all applicable local traffic laws, safety codes, and regulatory requirements.

## Table of Contents

<b>1. General</b> .....	<b>5</b>
1.1 Scope .....	5
<b>2. System Overview</b> .....	<b>6</b>
<b>3. Connecting a Laptop to the Nexus Omni</b> .....	<b>8</b>
3.1 Connecting with Ethernet .....	8
3.2 Connecting with Wi-Fi .....	9
3.3 Launching and Logging into the Installation Manager .....	10
<b>4. Understanding the System Interface and Operation</b> .....	<b>12</b>
4.1 Getting to Know the Intersection Manager User Interface .....	12
4.2 Operational Modes of the Sensors and Nexus Omni, and the Intersection .....	14
<b>5. Setting Up the Intersection</b> .....	<b>17</b>
5.1 Understanding Street Name # and Sensor Assignment .....	17
5.2 Configuring an Intersection .....	19
<b>6. Configuring Communication of Nexus Omni to Controller</b> .....	<b>21</b>
6.1 Selecting the TLS Method .....	21
6.2 Selecting the Detection Method .....	33
<b>7. Setting up City Network</b> .....	<b>46</b>
<b>8. Assigning the Nexus Omni</b> .....	<b>48</b>
<b>9. Configuring the Sensors</b> .....	<b>50</b>
9.1 Sensor Aiming .....	53
9.2 Sensor Calibration .....	58
9.3 Ingress Configuration .....	60

9.4 Approach Setup .....	64
9.5 Setting up Detection Zones .....	65
9.6 Assigning the Sensor to the Intersection .....	77
9.7 Complete Set Up of all Sensors .....	79
<b>10. System Tests .....</b>	<b>80</b>
<b>11. Registering the Intersection .....</b>	<b>82</b>
<b>12. Downloading Traffic Movement Counts (TMC) .....</b>	<b>84</b>
<b>13. Troubleshooting .....</b>	<b>87</b>
13.1 No BIUs Available .....	87
13.2 Detection Failure .....	88
13.3 Frame Detection Stops .....	89
13.4 Flashing the Smart Harness .....	89
<b>Appendix A. BIU Communication and Configuration .....</b>	<b>91</b>
<b>Appendix B. Warning Messages .....</b>	<b>92</b>
B.1 TLS Selection Warning .....	92
<b>Appendix C. Regular and Diamond Intersections .....</b>	<b>93</b>
<b>Appendix D. Support .....</b>	<b>94</b>
<b>Appendix E. Troubleshooting .....</b>	<b>95</b>
E.1 Scenario 1 – Successful Process Completion .....	95
E.2 Scenario 2 – Problems .....	95
E.3 Scenario 3 – Problems .....	96
E.4 Scenario 4 – Problems .....	96

## 1. General

### 1.1 Scope

This guide describes how to connect to the Installation Assistant, part of Intersection Manager 2602, to set up and configure the Nexus Omni and Sensors in an intersection.

#### Terminology

<b>Term/Abbreviation</b>	<b>Description</b>
Approach	Traffic direction. Also know as a <b>leg</b> .
Apps	Applications
BIU	Bus Interface Unit
CV	Connected Vehicle
DAU	Detector Actuation Unit
DHCP	Dynamic Host Configuration Protocol
FYA	Flashing Yellow Arrow
IM	Intersection Manager – Web-based user interface to configure the intersection
ITS	Intelligent Transport Systems
Mobility OS	Mobility Operating System
NEMA	National Electrical Manufacturers Association
NOC	NoTraffic Operations Center
NTCIP	National Transportation Communications for Intelligent Transportation System Protocol
RSU	Road Side Unit
SDLC	Synchronous Data Link Control
SIU	Serial Interface Unit
SSU	Signal Status Unit
TLS	Traffic Light Status
TMC	Traffic Movement Counts
TSC	Traffic Signal Controller

## 2. System Overview

NoTraffic AI Mobility Platform uses fused sensors and machine learning algorithms to detect, identify, classify, and track discrete road users at signalized intersections. Functioning as a traditional detection system, the NoTraffic Mobility Platform actuates detector inputs of traffic signal controllers for stop bar and advance detection. As a comprehensive traffic control platform, it also provides applications (Apps) that support safety metrics, performance metrics, connected intersection (CI), V2X, and other ITS functions. The NoTraffic Mobility Platform provides both local (field) and central (cloud) software user interfaces for managing, monitoring, controlling, and reporting, with 24/7/365 support and monitoring.

The NoTraffic Mobility Platform is composed of the following major hardware components:


- Type-1 Sensor - Detects and classifies road users using integrated video and radar in various weather and lighting conditions.
- Type-2 Sensor - Provides the same detection and classification capabilities as the Type-1 Sensor and adds a built-in C-V2X RSU for direct V2X applications..
- Nexus Omni - Installed in the cabinet and receives detection data from the Sensors and places calls to the traffic controller. The Nexus Omni connects to the cloud-based Mobility OS and runs applications like Optimization Mode for improved traffic safety and performance.
- Sensor Power Unit - Powers the Sensors and integrates with the Nexus Omni to control power supply to the Sensors.
- Smart Harness - A device that bridges existing analog Traffic Light System (TLS) and Detection communication cables with an Ethernet connection to enable seamless communication with the Nexus Omni.
- Antenna - The antenna ensures a reliable signal for LTE, Wi-Fi, and GPS.

The Sensors are compatible with standard camera mounting hardware using a 4" yoke-style configuration and existing infrastructure. They communicate with the Nexus Omni mounted inside the cabinet via Wi-Fi (up to 250 feet) or Ethernet. Additional Wi-Fi repeaters extend the range for distances exceeding 250ft. Sensors can use any 120–240 VAC power source, including luminaires via a NEMA Tap, eliminating the need for pulling cables to the cabinet. The Sensors combine vision and radar for object detection and classification. A Type-2 Sensor with built-in capabilities for Connected Vehicle (CV) applications is installed at each intersection.

The Nexus Omni is installed in the traffic signal equipment cabinet and connects to the TSC through a Smart Harness to SDLC (BIU or SIU), CI, or ABC, and NTCIP (where applicable). The Nexus Omni includes an embedded Intersection Manager (IM) application equipped with a user interface that allows viewing and editing of all real-time and configuration data of the Nexus Omni and Sensors. This browser interface is accessible by a user at the traffic signal equipment cabinet

via a wired or wireless connection. The Nexus Omni controls the Sensor Power Unit but does not supply power directly.


A schematic diagram of a typical NoTraffic system appears in the following figure.



### 3. Connecting a Laptop to the Nexus Omni

To configure the intersection using the IM application embedded on the Nexus Omni, connect a laptop to the Nexus Omni. You can connect to the Nexus Omni through the following methods:


- Ethernet
- Wi-Fi



Once connected, access the IM application to perform setup and configuration tasks.

#### 3.1 Connecting with Ethernet

1. Connect an Ethernet cable from your laptop to the RJ45 technician port labelled **8 MISC** on the front of the Nexus Omni.



**Note**

Ports 1–3 and 5–7 also support technician access if required.


### 3.2 Connecting with Wi-Fi

Use the Nexus Omni screen and control buttons to obtain Wi-Fi connection credentials for connecting to the embedded IM app as follows:

#### Note

Only one user must connect at a time.

1. Press the **NEXT** button to move the menu selection to **About**.



2. Press the **SELECT** button twice to move to option **2**.
3. Press the **NEXT** button to enable Wi-Fi access.  
The screen displays the Wi-Fi name, password and URL required for connecting.
4. Open Wi-Fi settings on your laptop.
5. Select the Wi-Fi network displayed by the Nexus Omni.
6. Enter the password displayed by the Nexus Omni.


**Note**

The connection session to the Nexus Omni remains active for 60 minutes. If the installation is not completed within this time, repeat the connection procedure to initiate a new 60-minute session and continue the installation.

To assist the user, a popup warning will appear twice before the session expires:

- The first popup appears 5 minutes before expiration.
- The second popup appears 1 minute before expiration.

Click **Extend To 60Min** to extend the session.



### 3.3 Launching and Logging into the Installation Manager


To begin configuring the intersection, launch the IM application embedded on the Nexus Omni. Log in using your technician credentials to access the setup and configuration tools.

After connecting to the Nexus Omni via Wi-Fi or Ethernet:

1. On your laptop, open a Google Chrome browser.
2. Access the IM application as follows:
  - Ethernet – type the URL **10.5.0.2:6080** and press Enter.  
On your laptop, go to **Network > Ethernet**. Under **DNS server assignment**, set the option to **Automatic (DHCP)**.
  - Wi-Fi – type the URL displayed by the Nexus Omni and press Enter.

3. On the login screen enter the credentials issued to you by NoTraffic as follows:

- **Email**
- **Password**



4. Click Continue.

The welcome window appears prompting you to begin the setup process.




5. Click **Let's start**.









## 4. Understanding the System Interface and Operation

### 4.1 Getting to Know the Intersection Manager User Interface

The dashboard opens, providing access to all tools for viewing, editing, and configuring the Nexus Omni, Sensors, and the intersection.

The following image and table describe the dashboard features.



# Item	Description
1	<p>Navigation Panel Menu including the following six wizard steps:</p> <ul style="list-style-type: none"> <li>                      Setting up the Intersection, see Section 5 - <a href="#">Setting Up the Intersection</a> </li> <li>                      Configuring the TLS Method, see Section 6.1 - <a href="#">Selecting the TLS Method</a> </li> <li>                      Configuring the Detection Method, see Section 6.2 - <a href="#">Selecting the Detection Method</a> </li> <li>                      Setting up City Network, see Section 7 - <a href="#">Setting up City Network</a> </li> <li>                      Configuring the Sensors, see Section 9 - <a href="#">Configuring the Sensors</a> </li> <li>                      System Tests, see Section 10 - <a href="#">System Tests</a> </li> <li>                      TMC, see Section 12 - <a href="#">Downloading Traffic Movement Counts (TMC)</a> </li> </ul>
2	<p>Nexus Omni Mode Displays the mode status of the Nexus Omni, see Section 4.2.1 - <a href="#">Nexus Omni and Sensor Modes</a></p>
3	<p>Intersection Mode Displays the mode status of the Intersection, see Section 4.2.2 - <a href="#">Intersection Modes</a></p>
4	<p>User Manual                       Displays the online User Manual.</p>

- After the initial configuration and while in wizard mode, the IM opens on the last screen it displayed.
- The icons on the navigation panel are enabled (illuminated) as you progress through the wizard steps. Uncompleted steps remain greyed out. Forward navigation is restricted, but you can return to previous steps and move between them.
- Once configuration is complete, the IM defaults to the Detection screen when opening.
- Once the wizard is completed (after system tests), you can move back and forth between steps.

### Warning

If you navigate back to the **Sensor aiming** after completing it and adjusting the zoom, a warning is displayed. Continuing, deletes all Sensor configurations from the preceding steps, including trajectories, lane-to-phase assignments, and detection zones.

### Warning

If you navigate back to the **Ingress configuration** after completing it and change the trajectories, all Sensor configurations from the preceding steps are deleted, including trajectories, lane-to-phase assignments, and detection zones.

## 4.2 Operational Modes of the Sensors and Nexus Omni, and the Intersection

This section provides an overview of the operational modes of the Nexus Omni and Sensors and the Intersection.

### 4.2.1 Nexus Omni and Sensor Modes

- **Factory** mode – the default settings configured during production. The units remain in this mode during the installation process until moved to Operational mode.
- **Operational** mode – the Nexus Omni receives detections from Sensors and sends them to the Traffic Signal Controller (TSC). The units remain in this mode until the Intersection switches to Managed mode.
- **Managed** mode – the NoTraffic Mobility Platform connects to the cloud-based Mobility Operating System, providing access to user interfaces for managing, monitoring, controlling, and reporting, with 24/7/365 support and monitoring.

#### 4.2.1.1 Moving Units from Factory to Operational Mode:

- The **Nexus Omni** switches to Operational mode after setting up the City Network, see Section 7 – [Setting up City Network](#).
- If connection to the city network fails, an error message is displayed, and the intersection installation is blocked, until the error is corrected.

#### Note

City Network is optional for Nexus Omni assignment, but if used, all parameters must be valid.

- If successful – the Nexus Omni switches to Operational mode, allowing the user to continue the setup process for the Sensors.
- The **Sensors** switch to Operational mode after:
  1. Completing the Sensor configuration wizard.
  2. Assigning them to the intersection, see Section 9.6 – [Assigning the Sensor to the Intersection](#).

#### 4.2.2 Intersection Modes

- **Factory** Mode – a new intersection with the Nexus Omni and Sensors units not yet installed.
- **Operational** Mode – the intersection enters Operational mode only when all hardware units are in Operational mode, and all required system tests are completed successfully. The intersection cannot switch to Operational mode if any unit ( Nexus Omni or Sensor) is not in Operational mode.
- **Managed** Mode – the NoTraffic Mobility Platform connects to the cloud-based Mobility Operating System, providing access to user interfaces for managing, monitoring, controlling, and reporting, with 24/7/365 support and monitoring.

##### 4.2.2.1 Moving the Intersection from Factory to Operational mode

Once the Nexus Omni and all Sensors are in Operational mode and all system tests passed, the intersection automatically switches to Operational mode. At this point, release the TSC from recall mode.

### To request the Intersection Registration

1. After running all system tests, the installer sends the intersection registration request.

The registration request includes the intersection status together with the following information:

- Unit's information – name and mode
- Intersection mode – Factory or Operational
- System tests results
- GPS location

2. The NOC receives the request and processes it. If an issue occurs, see [Appendix E – Troubleshooting](#).

## 5. Setting Up the Intersection


### 5.1 Understanding Street Name # and Sensor Assignment


A **Street name #** is a combination of a street name and one or two approaches (traffic directions).

- **Example 1:** One street name with two directions is entered as a single **Street name #**:
  - **Street name #1** – Main Street, two approaches: East + West Bound
- **Example 2:** Two street names, each with a different direction, are entered as two separate **Street name #'s**:
  - **Street name #1** – Main Street, one approach: East Bound
  - **Street name #2** – Side Street, one approach: West Bound

The number of Sensors installed at the intersection should correspond to the number of traffic approaches being monitored.

The following table describes the three possible **Street name #** setups with one Sensor installed per approach:





**Street name #1** Main Street

**Approach:** East Bound

Qty of Sensors: 1

**Street name #2** Park Street

**Approach:** West Bound

Qty of Sensors: 1

**Street name #3** Side Street

**Approach:** South Bound


Qty of Sensors: 1

**Street name #4** Fleet Street

**Approach:** North Bound

Qty of Sensors: 1

Total Sensors: 4



**Street name #1** Main Street

**Approach:** East Bound

Qty of Sensors: 1

**Street name #2** Park Street

**Approach:** West Bound

Qty of Sensors: 1

**Street name #3** Side Street

**Approach:** South Bound

Qty of Sensors: 1

**Street name #4** Fleet Street

**Approach:** North Bound

Qty of Sensors: 1

Total Sensors: 4

## 5.2 Configuring an Intersection

To configure an intersection, complete the following **Intersection & Installer Details**:

1. **Agency/City name** (mandatory).
2. Combination of the street name and its approach/es (mandatory):
  - **Street name #1.**
  - In the **Approach** list, select the appropriate direction/s associated with the street name being added.

**Intersection & Installer Details**

Agency/City name\*  
Phoenix

Street name #1\*  
McClintock Drive

Approach  
North + South

Street name #2\*  
Main Street

Approach  
East + West

Add Street +

Intersection name\*  
McClintock Drive & Main Street

\*This field is required.

Your name\*  
James Smith

Phone number\*  
1573 777 2222

Save

### Note

- Enter the **Street name** according to your agency's naming convention. If no convention exists, use the name as it appears in Google Maps or Apple Maps for accuracy.
- A minimum of two **Street name #s** are required.

1. If required, click **Add street +** to add an additional **Street name #**.
2. To remove a **Street name #**, click **Remove street -**.

Street name #1\*  
McClintock Drive

Approach  
North + South

Street name #2\*  
Main Street

Approach  
East

Street name #3  
Main Street2

Approach  
West

Add street + Remove street -

3. **Intersection name** (mandatory).

**Note**

The IM automatically generates the **Intersection name** by combining the **Street names** you added. You can edit this name to make sure it is unique and distinctly identifies the intersection.

4. **Your name** (mandatory) - enter the name of the system installer, who can be contacted by the NOC for follow up.

5. **Phone number** (mandatory).

6. Verify the following:

- All street names (**street name #**) have been added and there are no duplicates.
- The quantity of directions for approaches corresponds to the quantity of Sensors that are to be installed.
- All details are correct.

The screenshot shows a form titled "Intersection & Installer Details" with the following fields and values:

- Agency/City name\*: Phoenix
- Street name #1\*: McClintock Drive
- Approach: North + South Bound
- Street name #2\*: Main Street
- Approach: East + West Bound
- Intersection name\*: McClintock Drive & Main Street
- Your name\*: James Smith
- Phone number\*: 1573 777 2222

A "Save" button is located at the bottom of the form.


7. Click **Save**.

You are redirected to the detection page.

## 6. Configuring Communication of Nexus Omni to Controller

The Nexus Omni communicates with the TSC using one of the following methods:

- Digitally using NTCIP (for OPT/status only; not used for placing calls)
- Serially using SDLC
- Analog using C1



**TLS** uses NTCIP, SDLC or C1.

**Detection** uses SDLC or C1.

### Note

The most common configuration of communication with the TSC uses one Smart Harness for Detection (via SDLC or C1) and one Ethernet cable for TLS (via NTCIP).

### 6.1 Selecting the TLS Method

The following window is displayed in the first wizard session.

Select a TLS method from the following option, in order of preference:

- NTCIP – preferred method, if supported by the controller.
- SDLC – use if NTCIP is not supported.
- C1 (Caltrans) – Use only if neither NTCIP nor SDLC is available.
- ABC (SSU) – use only if neither NTCIP nor SDLC is available.



After completing the initial wizard, if you decide to change the TLS method, a message prompts you to either confirm your current selection or cancel and return to the detection selection window. See Section [B.1 – TLS Selection Warning](#).

### Tip

During configuration, you can return to the TLS Method selection by clicking **Connection types**.



### 6.1.1 Setting up TLS – NTCIP

1. Enter the parameters for the **Controller** and **NoTraffic** networks fields as follows:

- a. Select and enter **Controller IP**. The IP address on the network.


### Note

Most controllers include an ENET 2 port, which is the preferred connection for this setup. If connecting through a switch, an IP address must be assigned by the City's IT or network administrator.


- b. Select and enter the **Controller port**. This is the port used by the controller for NTCIP communication.
  - For Econolite controllers, the default port is **501**.
  - For most other controllers, the default is typically **161**.

To confirm the correct port, check the controller’s configuration menu—this is usually found under the Communications or SNMP Settings submenu.


- c. Select and enter **Community**. The default is **public**, but this may vary. If uncertain, check the NTCIP menu on the controller to view the configured community name.
  - d. Select and enter **NoTraffic IP**. The IP of the Nexus Omni is provided by the city/client.
    - If connecting directly to the controller, use an IP address on the same network as the controller.
    - If connecting via a city-owned switch, the IP address must be assigned by NoTraffic.
  - e. Select and enter **NoTraffic Netmask**.
  - f. Select and enter **NoTraffic Unit Gateway**.
2. Click **Save And test Connection**.



3. When **successfully connected**, check all channels, phases and overlap are active and running. Make sure each **Phase** color status and timing changes are synchronized with the actual traffic light head’s color and timing changes.



4. If the **connection to the controller failed**, contact the NOC, see Section [Appendix D - Support](#) to resolve the issue.



5. Click **Next**.  
The display refreshes and moves to Setting up City Network.



### 6.1.2 Setting up TLS – SDLC

The following figure and table describe the **TLS – SDLC** screen.


The screenshot shows the 'TLS - SDLC' configuration interface. It includes a table for mapping channels to types and phases, a status bar for channels, a table for phase types, a diagnostics log, and navigation buttons for connection types, guidance, and saving configuration.

# Item	Description
1 Add load switch +	Displays the add load switch window to map channels to types and phases.
2 Mapping Table	Displays the relational status of the Channel/Load switch, Type, Phase and Opposing phase.
3 Channels	Displays the status (red, yellow, green) of each load switch (channel).
4 Table of mapped phases to types	Displays the status of phases with relation to types (Vehicles, Flashing Yellow Arrow, Pedestrian).
5 TLS – SDLC Diagnostics	Displays messages transmitted on the SDLC bus.
6 Connection types	Returns to the Detection Method window (page).
7 Guidance	Displays help menu.
8 Save Configuration	Saves the configuration and moves to Setting up City Network.

### To configure TLS - SDLC

1. Click **Add load switch +**.
2. Select the **Channel/Load switch**.
3. Select the **Type** (Vehicles or Flashing Yellow Arrow or Pedestrian).
4. **Select the Phase** (1 to 8) that is connected to this channel (load switch).
5. If the type is **FYA** you must select the **Opposing phase** (1 to 8) that controls the conflicting through movement connected to the same load switch (channel). The opposing phase typically refers to the phase that vehicles encounter when traveling in the opposite direction through the intersection.

As phases are added (mapped), the table of phase-to-type mappings updates immediately on the screen to display the actual status. Check the phases are active and running. Make sure each Phase's color status and timing changes are synchronized with the actual traffic light head's color and timing changes.



6. Repeat steps 1 to 5 for all channels (load switches) in the cabinet. This is limited to a maximum of 16 lines.

Take care to check all the channels (load switches) are populated.

7. Click **Save configuration**.
8. Click **Next**.

The display refreshes and moves to Setting up City Network.

### 6.1.3 Setting up TLS – C1

The following figure and table describe the **TLS – C1** screen.

**TLS - C1**

1

Cable: C1 | C1 Configurations: CALTRANS TEES Standard

Cable	Pin number	Type	Phase	Opposing phase
C1	2	Vehicle - Red	1	2
C1	3	Not in use	-	-
C1	4	Vehicle - Yellow	1	2
C1	5	Vehicle - Red	2	1
C1	6	Vehicle - Green	2	1
C1	7	Vehicle - Flashing Yellow Arrow	2	1
C1	8	Vehicle - Red	3	4
C1	9	Vehicle - Green	3	4
C1	10	Vehicle - Yellow	3	4
C1	11	Vehicle - Red	4	3
C1	12	Vehicle - Green	6	3
C1	13	Vehicle - Green	8	3
C1	15	-	5	6

2

3

Pin Table

2	3	4	5	6	7	8	9
10	11	12	13	15	16	17	18
19	20	21	22	23	24	25	26
27	28	29	30	31	32	33	34
35	36	37	38	85	86	87	88
89	90	91	92	93	94	95	96
97	98	99	100	101	102	103	

4

Phase	1	2	3	4	5	6	7	8
Vehicle	●	●	●	●	●	●	●	●
Flashing Yellow Arrow	←							
Ped	⚡	🚶	⚡	🚶				

5

← Connection types

6

Save configuration

7

Next

#	Item	Description
1	Configuration	
2	Mapping Table	Displays the relational status of controller output pins to the type and phase.
		<p><b>Note</b></p> <p>The opposing phase is not currently in use and is reserved for future implementation.</p>
3	Pin Table	Displays the status (blue or gray) of each controller output pin.
4	Table of mapped phases to types	Displays the status of phases with relation to types (Vehicles, Flashing Yellow Arrow, Pedestrian).
5	Connection types	Returns to the Detection Method window (page).
6	Save configuration	Saves the configuration and moves to the wizard step. Closes the TLS - SDLC window.
7	Next	Refreshes the display and moves to Setting up City Network.

The Intersection Manager is preloaded with the following default pin assignment configurations:

- MODE 0 – CALTRANS TEES Standard
- MODE 1 – NY DOT Standard
- MODE 2 – DADE County
- MODE 3 – Plano Texas
- MODE 5 – North Carolina
- MODE 6 – HOV Gate
- MODE 7 – Broward County

**Note**

If your agency uses a different configuration, you must manually set the pin assignments to match the cabinet setup.

Each mode includes default values for:

- Cable
- Pin Number
- Type (Vehicle Red, Vehicle Green, etc)


**To configure TLS - C1:**

1. In the **Cable** list select a cable. This determines the cable combination used for detection from the following:

- C1



2. Select a **configuration** for the selected cable. Predefined modes (Mode 0 through Mode 7) are available as configuration templates.



**To view and assign phases:**

After selecting a mode, the system automatically populates the pin assignment table with the corresponding TLS-related entries.

- Check if the preset values match your cabinet setup:
  - If they match - Select the **Phase** (1 to 8) and **Opposing phase** that correspond to the **Pin number** (load switch) on the traffic light head.
  - If they do not match - Manually adjust the following field in the pin assignment table:
 

**Type** - Defines the road user type (Vehicle, Pedestrian, Overlap, or Not in use) associated with the pin:

This allows you to accommodate field-specific variations.

### Note

To save the configuration, you must assign a valid type to each pin. If a pin is not in use, set the **Type** to: **Not in use**.

As phases are added (mapped), the phase-to- type mapping table updates immediately to reflect the current status.

- Check that each phase is active and functioning.
- Confirm that the color status and timing of each mapped **Phase** match the actual light head's color and timing changes.

For example, Phase 2 is correct. Phase 4 is incorrect and must be remapped.

Phase	1	2	3	4	5	6	7	8
Vehicle	●	●	●	⚠	●	●	●	●
Flashing Yellow Arrow	↔							
Ped		✋	🚶		✋		🚶	

4. Repeat this process for each **Pin number** (load switches) individually. Make sure that all TLS phases in use are correctly configured. Take care to check the following:
  - Assign three pins per traffic light head (Red, Yellow, Green).
  - Assign two pins per pedestrian head (typically Walk and Don't Walk).
  - Make sure each pin is either:
    - Mapped to a **Phase**, or
    - Set to **Not in use**

Cable	Pin number	Type	Phase	Opposing phase
C1	2	Vehicle - Red	1	2
C1	3	Not in use	-	-
C1	4	Vehicle - Yellow	1	2
C1	5	Vehicle - Red	2	1
C1	6	Vehicle - Green	2	1
C1	7	Vehicle - Flashing Yellow Arrow	2	1

3 pins for the phase

5. Click **Save Configuration**.
6. Click **Next**.
7. The display refreshes and moves to Setting up City Network.

### 6.1.4 Setting up TLS – ABC (SSU)

The following figure and table describe the **TLS – ABC** (SSU) screen.

The screenshot shows the 'TLS - ABC' configuration interface. It includes a mapping table, a pin status table, a phase-to-signal type mapping table, and navigation buttons. Numbered callouts 1 through 6 highlight specific UI elements as described in the table below.

#	Item	Description
1	Mapping Table	Displays the relational status of controller output pins to the type and phase.
		<p><b>Note</b></p> <p>The opposing phase is not currently in use and is reserved for future implementation.</p>
2	Pin Table	Displays the status (blue or gray) of each controller output pin.
3	Table of mapped phases to types	Displays the status of phases with relation to types (Vehicles, Flashing Yellow Arrow, Pedestrian).
4	Connection types	Returns to the Detection Method window (page).
5	Save configuration	Saves the configuration and moves to the wizard step. Closes the TLS – SDLC window.
6	Next	Refreshes the display and moves to Setting up City Network.

Each SSU monitors (senses) the red, yellow, and green signals for a single traffic signal Phase (1–8).


When you assign an SSU to a Phase, it automatically maps three output pins – one for each signal color.

The UI updates dynamically to reflect the actual signal states on-screen.

make sure each assigned Phase is active, valid, and synchronized with the physical traffic head behavior.

**To configure TLS - ABC (SSU)**

1. Click **Add pin +**.
2. Select the **SSU Spade ID** (as labeled on the spade connector).  
The lower spade row corresponds to the SSU connections.



3. Select the **Type** (Vehicles or Flashing Yellow Arrow or Pedestrian).
4. Select the **Phase** (1 to 8) that this SSU monitors.  
For example, Phase two is correct, and Phase four is incorrect and must be remapped.

Phase	1	2	3	4	5	6	7	8
Vehicle	●	●	●	⚠	●	●	●	●
Flashing Yellow Arrow	↔							
Ped	✋	🚶	✋	✋	✋	✋	🚶	✋

- Repeat steps 1 to 4 for all connected spades in the cabinet.

You must add three pins for traffic light vehicle head's load switches (red, yellow, green), or two pins for pedestrian head's load switches.

SSU number	SSU spade ID	Type	Phase	Opposing phase
1	1	Vehicle - Red	1	
1	2	Vehicle - Green	2	
1	3	Vehicle - Yellow	3	

3 pins for the phase (via SSU)

- Verify that all pins (load switches) are populated and correctly assigned.
- Click **Save Configuration**.
- Click **Next**.

The display refreshes and moves to Setting up City Network.

## 6.2 Selecting the Detection Method

Select one of the following detection methods based on the available TSC interfaces:

- **SDLC**
- **C1**
- **ABC (DAU)**

### Detection Method



If a detection method is already configured, a message prompts you to either confirm your current selection or cancel and return to the detection selection window. See Appendix [B.1 - TLS Selection Warning](#).

### Tip

During configuration, you can return to the Detection Method selection by clicking **Detection methods**.


← **Detection methods**

### 6.2.1 Setting up Detection – SDLC

The following figure and table describe the **Detection – SDLC** screen.

#### Note

This screen and configuration process also apply to SIU detection. The SIU setup is equivalent to the BIU setup shown here—the only difference is the SIU-specific output table, which is included later in this section.




#	Item	Description
1	BIU	Displays four BIUs and their status (see Section 6.2.1.1 – BIU – Bus Interface Unit).
2	Frames	Displays the count of how many frames are transmitted (received, sent, bad) on the SDLC bus.
<p><b>Note</b></p> <p>Observe the <b>Frames</b> status. The counter for received frames must increase continuously. If no frames are received or the count stops (no SDLC communication), refer to Section 13.2 – Detection Failure and Section Appendix A – BIU Communication and Configuration</p>		
3	Connection types	Returns to the <b>Detection Method</b> window (page).
4	Guidance	Displays help menu.
5	SDLC Diagnostics	Displays messages transmitted on the SDLC bus.
6	Choose BIU for configuration	Select a BIU and simulate detection. Each BIU has 16 outputs (detectors).
7	Finish	Saves the configuration and moves to the next page. Closes the DETECTION – SDLC window.

### 6.2.1.1 BIU – Bus Interface Unit

The Nexus Omni acts as a BIU device from the controller's perspective.

The IM displays the status of four BIUs as follows:




- **Busy** (red) – BIU is used by another system and cannot be used by NoTraffic.
- **BUSY NT** (green) – BIU is temporarily used by the NoTraffic simulation.
- **Free** (green) – BIU is free to be used by NoTraffic.
- **Off** (gray) – BIU is not enabled in the controller programming.

#### Note

BIUs with the status BUSY (red) or OFF (gray) are not available for NoTraffic use and cannot be selected as a BIU.

1. If none of the BIUs are free (green), do one of the following:

- Enable an OFF (gray) BIU in the controller. Refer to the guidance in Section 13.1 - No BIUs Available.




- Free a BUSY (red) BIU by removing an old system from the cabinet.
- Click **Skip for now** to skip this step.

2. To select a BIU for detection configuration, you must select a BIU that is **Free** (green) from the **BIU number** list.



3. To simulate a detection:

- In the **Output** list, select an output number linked to the free (green) BIU to place a test call on it.



BIU Output Assignments		SIU Output Assignments	
BIU	Outputs	SIU	Outputs
BIU 1	1-16	SIU 1	1-24
BIU 2	17-32	SIU 2	25-48
BIU 3	33-48	SIU 3	49-72
BIU 4	49-64	SIU 4	73-96
		SIU 5	97-120

- b. In the **Seconds** list select the time to simulate the detection for this **Output**.

### Tip

Make sure the selected time is sufficient for you to reach the controller.


- c. Click **Simulate Detection at Controller**.

### Tip




Alternatively, in SDLC detection, verify the simulation is working by checking the controller:

- In the controller, verify the detector is on, see Section [13.2 - Detection Failure](#).

4. Wait for the selected time while the simulation is **Running**.



5. After the selected simulation time has passed, a final response is displayed. The following table describes the actions to take during the entire process.

Response Displayed	Response State	Action
	Failed	Do one of the following: <ul style="list-style-type: none"> <li>• Retry</li> <li>• See Section 13.2 - <a href="#">Detection Failure</a></li> <li>• Contact the NOC, see <a href="#">Appendix D - Support</a>.</li> </ul>
	Succeed	Click <b>Finish</b> . <div style="text-align: right; margin-top: 20px;">  </div>

### Warning

You must place a successful test call before drawing detection zones. This is required for the system test to pass.

### 6.2.2 Setting up Detection – C1

The Intersection Manager is preloaded with the following default pin assignment configurations:

- MODE 0 – CALTRANS TEES Standard
- MODE 1 – NY DOT Standard
- MODE 2 – DADE County
- MODE 3 – Plano Texas
- MODE 5 – North Carolina
- MODE 6 – HOV Gate
- MODE 7 – Broward County

**Note**

If your agency uses a different configuration, you must manually set the pin assignments to match the cabinet setup.

Each mode includes default values for:

- Cable
- Pin Number
- Detector / Index Number

**To configure C1 Detection**

1. In the **Cable** list select a cable. This determines the cable combination used for detection from the following:

- C1



2. Select a **configuration** for the selected cable. Predefined modes (Mode 0 through Mode 7) are available as configuration templates.



### To view and edit Detection pin assignment

After selecting a mode, the system automatically populates the pin assignment table with the corresponding detection-related entries.

1. Edit Pin Assignments (if needed).

If your actual cabinet configuration differs from the default, manually adjust the following fields in the pin assignment table:

- **Cable**
- **Pin number**
- **Detector Index / Function**

This allows you to accommodate field-specific variations.

**Detection - C1**

Cable: C1 | C1 Configurations: CALTRANS TEES Standard

Simulate detection

Detector index: 17 | Seconds: 5 | **Simulate detection at the controller**

\*During simulation, verify detection in the controller. See guidance


Cable	Pin number	Detector Index/Function
C1	39	2
C1	40	16
C1	41	8
C1	42	22
C1	43	3
C1	44	17
C1	45	9
C1	46	23
C1	47	6
C1	48	20
C1	49	12
C1	50	26

**Save configuration** | **Next**

2. Click **Save configuration**.
3. Repeat this process for each pin number individually. Make sure that all detectors in use are correctly configured.

## To simulate a detection

1. In the **Detector index** list select a detector number.



The screenshot shows a web interface titled "Detection - C1". At the top, there are two dropdown menus: "Cable" set to "C1" and "C1 Configurations" set to "CALTRANS TEES Standard". Below these is a section titled "Simulate detection" which contains two more dropdown menus: "Detector Index" set to "17" and "Seconds" set to "5". To the right of these dropdowns is a blue button labeled "Simulate detection at the controller".

2. In the **Seconds** list select the time to simulate the detection for this output.

### Note

You cannot simulate an output that is not displayed in the Detector Index number column.

### Tip

Make sure the selected time is sufficient for you to reach the controller.

3. Click **Simulate detection at controller**.

### Note

You must run at least one simulated detection for the system test to pass

4. Check on the controller screen that the selected **Detector number** is working. See Section 13.2 - [Detection Failure](#) for guidance on how to view the detector status.

Input	Desc	Control	Type	Index
1	C1-39	Veh Det	Call	2
2	C1-40	Veh Det	Call	16
3	C1-41	Veh Det	Call	8
4	C1-42	Veh Det	Call	22
5	C1-43	Veh Det	Call	3
6	C1-44	Veh Det	Call	17
7	C1-45	Veh Det	Call	9
8	C1-46	Veh Det	Call	23
9	C1-47	Veh Det	Call	6
10	C1-48	Veh Det	Call	20
11	C1-49	Veh Det	Call	12
12	C1-50	Veh Det	Call	26
13	C1-51	PreemPt	InPut	1
14	C1-52	PreemPt	InPut	2
15	VC1-53	Man Ctrl	Enable	1

**Tip**


Best practice - repeat steps 1 to 4 for all C1 detectors in use.

5. Click **Next**.

### 6.2.3 Setting up Detection – ABC (DAU)


#### To configure ABC (DAU) Detection:

1. Click **Add DAU spade +**.



2. Select a **DAU spade ID** (as labeled on the spade connector).

The upper spade row corresponds to the DAU connections.



3. Select a **Detection number**. This is the controller detector number (input file).

**Simulate detection**

\*During simulation, verify detection in the controller. [See guidance](#)

DAU number	DAU spade ID	Detection number
1	IN1	1
1	IN2	2
1	IN3	3
1	IN4	4
1	IN5	5
1	IN6	6
1	IN7	7
1	IN8	8
1	IN9	9
1	IN10	10
1	IN11	11
1 +	IN12 +	+ <input type="button" value="x"/>

Add DAU spade +


4. Repeat steps 2 to 3 to add each spade number individually. Make sure you configure all detectors in use.

**Note**

You cannot simulate an output that is not displayed in the **DETECTOR NUMBER** column.

**To simulate a detection**

1. In the **Detector number** list select a detector number.



2. In the **Seconds** list select the time to simulate the detection for this output.

**Tip**


Make sure the selected time is sufficient for you to reach the controller.

3. Click **Simulate detection at the controller**.

**Note**

You must run at least one simulated detection for the system test to pass

4. Check on the controller screen that the selected **Detector number** (indicated by an **X**) is working. See Section 13.2 – [Detection Failure](#) for guidance on how to view the detector status.



**Tip**

Best practice - repeat steps 1 to 4 for all SPADE detectors in use.


5. Click **Finalize Configuration**.


## 7. Setting up City Network

Setting up the **City Network** is optional. If you do not need to connect to the city network – click **Skip**.

### Note


To set up the city network in the cabinet you need to connect an ethernet cable from the City switch to the **CITY NW** port 4 on the Nexus Omni.



1. On the side navigation bar, click .
2. The **Intersection name** is automatically populated by the software as described in Section 5.2 – [Configuring an Intersection](#).
3. If the City or agency requests that the system be connected to their WAN, the following values must be provided by the City or agency's network administrator.
  - a. Click **IP Address** and enter the address.
  - b. In the **Netmask** list select the netmask.
  - c. Click **Gateway** and enter the address.  
If not required, leave these fields unchanged.
4. Click **Save**.

**Note**


If incorrect parameters are entered, the following error message displays:




Click **Go Back** to review and correct the network settings, or click **Skip** to skip this step.

## 8. Assigning the Nexus Omni

1. Click **Continue** to assign the Nexus Omni.




2. Wait while the system attempts to assign the Nexus Omni.




3. If **Completed successfully**, click **Ok**

### Note

The assignment process takes up to 4 minutes and automatically retries if needed



4. If **Failed**, click **Ok**. You cannot continue and must contact the NOC, see [Appendix D - Support](#).



## 9. Configuring the Sensors

Sensors are supplied in factory mode by default. After physically installing a Sensor at an intersection, it must be configured. Configuration involves five sequential steps:

- Sensor aiming
- Sensor calibration
- Ingress configuration
- Approach setup
- Detection zones

### Overview of the Configuring Stage

- Initial Setup
- When you begin the configuration process, the initial window below is displayed.

#### Note

In wizard mode, this screen appears only once with the message **Let's start**. Afterward, the system skips to step 2.




1. Click **Let's Start**.

You must select a Sensor to configure. The camera views of all connected Sensors are displayed in a quad view.

2. Click the video feed of the Sensor you want to configure.

- Each Sensor displays its own configuration progress in the lower-right corner of its screen view, indicated by a set of green check marks. These marks represent completed steps for that specific Sensor only – not for the entire intersection or other Sensors.



**Note**

Initially, the Sensor's name is its hardware ID.


After assigning a name in the **Sensor aiming** step (see Section 9.1 – [Sensor Aiming](#)), the Sensor name replaces the hardware ID.

**Note**


A Sensor can only be assigned after completing all five configuration steps, see Section 9.6 - [Assigning the Sensor to the Intersection](#).

**Note**

If no sensor is detected, the **No Sensor Unit connected** window appears. To resolve this, make sure that at least one Sensor is properly connected and powered.

**Navigation Features During Configuration**

Two navigation tools in the top right of the screen are available throughout all five configuration steps:

**Intersection view**


- Click **Intersection view** to return to the quad view window which displays all Sensor camera feeds.

**Guidance**

- Click **Guidance** to access the on-site Sensor aiming video guide.

## 9.1 Sensor Aiming

The following figure describes the Sensor aiming screen.



#	Item	Description
1	Approach	Select the direction of traffic flow the Sensor monitors.
2	Inner	Select if more than one Sensor is viewing the same approach.
3	Sensor name	Confirm or edit the Sensor name.
4	Zoom and Focus	Use to zoom and focus the camera manually.
5	Save	Click to confirm and save the Sensor configuration.
6	Play live streaming	Video control function that shows the live stream video feed from the selected Sensor.
7	Retake snapshot	Captures and freezes the current frame for aiming and alignment purposes.

### 9.1.1 Approach

- In the **Approach** list, select the street name and direction combination. When two directions (**Approaches**) have been assigned to a **street name #**, for example north + south bound; two street name and direction combinations are displayed for selection, one for each of the street's directions (north + south). See SU assignment in Section 5 - [Setting Up the Intersection](#).

#### Note

Make sure you select the street name and direction combination for the Sensor you are aiming.

### 9.1.2 Inner

If more than one Sensor is viewing the same approach, there are two intersection configurations as follows:

1. **Regular** (non-diamond) intersection - make sure each Sensor is assigned a unique Sensor name and do not select any Sensor as **Inner**.
2. **Diamond** Intersection - you must designate one of the Sensors as the inner. Select **Inner** for the first Sensor in the approach.

See [Appendix D - Support](#) for explanation of the two types.

### 9.1.3 Sensor Name

The IM automatically generates the **Sensor name** by combining the street name and direction combination you selected in step 1. You can edit this Sensor name to make sure it is unique and distinctly identifies the street for this Sensor.


#### Note

- **Sensor name** should not contain spaces.
- Changes to the approach selection reset it to its default name.

### 9.1.4 Zoom and Focus

The **Zoom** and **Focus** controls are used to aim the Sensor. When aiming, make sure the following two key features are properly accounted for:

- **Intersection Box**
- **Stop Lines**



**To configure Zoom and Focus:**

1. Click and slide the zoom bar to adjust the camera zoom. Make sure the camera is fully zoomed out.

**Tip**

Recommend doing this in live streaming mode.

2. Aim the Sensor so that the Stop Line and Intersection Box are centered between the two orange vertical lines.


**Note**

The entire Intersection Box does not need to be visible in a single Sensor's view. Capturing approximately half of the box is sufficient, as full coverage is achieved through the combined view of all four sensors.


**Note**

To enable **Ped Protect**, the entire crosswalk must be visible.

3. Adjust the red dot by moving it toward the farthest visible point of the approaching road, without compromising step 2.




For curved roads: Make sure the aiming follows the road's natural curvature and does not shift too far to the right or left. The Sensor must still capture approaching vehicles as they enter the intersection.



#### 4. Zoom & Focus:

- a. **Zoom** in until the Stop Line is positioned midway between the two orange vertical lines, with its width spanning at least half the distance between them. Make sure the Stop Line remains within the orange vertical lines.
- b. **Focus** adjustment is manual or automatic, depending on the hardware and agency setup:
  - i. **Manual focus** – some Sensors require manual focus. If your Sensor supports manual focus, use the **+** and **-** icons to adjust focus.




#### Tip

Perform adjustments in live streaming mode for best results. Before adjusting, unlock the focus using the toggle. A warning message appears when unlocking.

- ii. **Auto focus** – some Sensors are equipped with auto-focus. In this case, the system automatically adjusts focus and displays a spinner while the image refreshes. No manual

focus adjustment is needed.



### Note

Focus can only be adjusted during the calibration step in the setup wizard. To change focus afterward, exit calibration mode in the NOC Tools.

### 9.1.5 Save


1. Click **Save**. You are redirected to **Sensor calibration**.

### Warning

If you return to the the **Sensor aiming** step after completing it and adjusting the zoom, a warning is displayed. Continuing deletes all Sensor configurations from the previous steps, including trajectories, lane-to-phase assignments, and detection zones.

## 9.2 Sensor Calibration

In this step, you calibrate the distance and dimensions captured by the Sensor into real-world measurements. The following figure describes the Sensor calibration screen.



#	Item	Description
1	Controls	Control tools for car placement.
2	Select car	Select the car to be placed.
3	Next car	Select to place the next car.
4	Finish calibration	Click to confirm and save the Sensor calibration.

### Placing and Adjusting 3D Car Models

Three 3D car models must be placed in the scene to serve as reference points for detection. The 3D car models must be positioned at different locations within the lane or different lanes (if possible) for optimal detection accuracy. During placement, each 3D car model can be rotated, scaled, and aligned as needed.

1. Click **Place First Car**. Then position and place the 3D car model as described below. Make sure that **at least three** 3D car models are placed in different positions for accurate detection.

#### Tip

Double-click the approximate car location to speed up the placement process.

**Note**

Preferred locations:

- Near the stop line – Just behind the visible stop line in the screen view.
- Midway in the lane – Approximately in the center of the lane.
- Far back in the lane – Near the horizon point.

2. Move the 3D Car Model.

- Press ← (left) and → (right) to move sideways.
- Press ↓ (down) and ↑ (up) to move forward or backward.

3. Align the 3D Car Model with the traffic flow direction by matching its orientation with the visible vehicles in the screen view. Make sure the 3D car model is parallel to the street lanes and aligned with the horizon point.

Rotate the 3D car model:

- Press **A** and **D** to rotate horizontally.
- Press **W** and **S** to rotate vertically.
- Press **Q** and **E** to adjust the tilt angle.

4. Scale the 3D Car Model to match the proportions of the adjacent visible vehicles in the screen view.

Adjust the scale:

- Press [ (open square bracket) to decrease size.
- Press ] (close square bracket) to increase size.


**Note**

The 3D default car model is sized to match a Tesla Model 3.

5. Modify the opacity of the 3D car model using the **Car opacity** slider.


6. When the first 3D car model is correctly placed, click **Next car** and repeat steps 1–5 for the second and third 3D car model placements.

7. Click **Finish calibration** to complete the process. The following figure describes the completed **Sensor Calibration** step.




### 9.3 Ingress Configuration

In this step you set up the stop line and trajectories that are viewed by the Sensor. The following figure shows the **Ingress configuration** screen.



**To add a stop line:**

1. Click **Add stop line**.
2. Select at least 2 points on the street view that represent the start and the end of the stop line. The stop line is drawn between these points in red.




3. If the actual stop is not straight, you can select multiple points along its path to trace the shape accurately.
4. If the stop line is incorrect, click **Delete stop line** and repeat steps 1-3.

### To add a trajectory:

In this step you draw a trajectory for every possible vehicle movement through the intersection

- A single lane can have multiple trajectories for different directions, such as right turn and straight.
- Add each trajectory one at a time, starting from one side of the view and working across.



#### Note

Make sure that the trajectories do not overlap, as this may interfere with subsequent lane creation steps


#### Note

Lane IDs are used for internal purposes and do not follow sequential numbering. If a lane is deleted and a new one is added, the numbering will skip, for example: 1, 2, 4.

1. Click **Add trajectory +**.
2. Select at least two points on the street view that represent the trajectory of the flow of the traffic. If the actual trajectory is not straight, select multiple points along its path to trace its shape accurately.

**Note**

Start the trajectory as far back as possible, near the horizon point and draw it through to the exit point. This defines the detection zone boundary limit.



3. Select the number of the **Lane**.
4. Select the **Direction**.
5. Click **Finish Creation**.
6. Repeat steps 1 to 5 to add more trajectories.
7. Click **Finish annotation** after adding all lane trajectories.

**Note**


If an error occurs, follow the instructions provided in the error message.

**Warning**


If you return to the **Ingress configuration** after completing it and make changes to the trajectories, all Sensor configurations from the previous steps are deleted. This includes trajectories, lane-to-phase assignments, and detection zones.

## 9.4 Approach Setup

1. Click  to select a lane to add to a phase.




2. Select the **Vehicle phase**.




3. Repeat steps 1 to 2 to add all lane's vehicle phases.

4. Click **Finish**.



## 9.5 Setting up Detection Zones

The Intersection Assistant generates colored lane zones that define where to place **Detection Zones**. The following figure shows an example intersection and does not depict the same intersection as the previous image.



Before proceeding, make sure that the colored lane zones match the actual lane layout. These zones are framed by the trajectory lines you created in the **Ingress Configuration** step, see [Ingress Configuration](#). The zones extend from the farthest trajectory points on the trajectory lines to the **Stop Line**.

## To adjust lane zones

If the colored lane zones appear misaligned or do not match the physical lane layout.

1. Return to the **Ingress Configuration** step.
2. Adjust the trajectory lines to shift zone boundaries (e.g., move a zone left or right).
3. Return to this step to confirm that the colored zones now align correctly with the lanes.

## To resolve a configuration error

If the system detects an error, a popup message appears with guidance.

1. Follow the instructions in the following popup to fix the configuration.

### ⚠ Configuration Error!

Something went wrong during the sensor configuration.  
Please retry by following the steps carefully.

#### 1. Sensor calibration:

##### Position the 3D Car Models in the following locations:

- **Near the stop line** – Just behind the visible stop line in the screen view.
- **Midway in the lane** – Approximately in the center of the lane.
- **Far back in the lane** – Near the horizon point.

##### Align the 3D Car Model with the traffic flow by ensuring:

- It matches the orientation of visible vehicles.
- It is parallel to the street lanes and aligned with the horizon point.
- It is scaled correctly to match the size of adjacent vehicles.

#### 2. Ingress configuration

##### Stop Line:

- Select at least **two points** on the street view that represent the start and end of the stop line.


##### Trajectories:

- Add trajectories **sequentially**, ensuring they move **from one side of the view to the other**.
- Select **at least two points** to define the traffic flow trajectory.
- If the trajectory is not straight, select **multiple points** to accurately trace the shape.
- Start the trajectory **as far back as possible**, just below the horizon point

Close

**Note**

Upload previously saved detection zones or download current detection zones for future use, as shown in the following figure.



**Upload detection zones**


All existing detection zones will be removed (both published and unpublished). Detection zones restored from backup will be **published** to the Nexus Unit immediately. Click OK to **overwrite** all detection zones from backup file.

**Download detection zones**


Only **published** detection zones will be downloaded. Click OK to confirm and download as backup file.

**9.5.1 To Create a Detection Zone**

1. Click **Detection Zone**.



2. Select four vector points within the colored lane to define the detection zone. The detection zone must remain entirely inside the colored lane and will appear superimposed once created.



3. Fill in the required fields. After completing each field, click **Next** to proceed.
  - a. Enter a descriptive name for the **Detection zone name**.
  - b. Select an **Output number**.
  - c. Select the **Output type**.
  - d. Select the **Vehicle detection type**.

**Detection Zones** (\*only published zone will effect controller)

**DETECTION ZONE SETUP**

Detection zone name

Output number

Output type

Vehicle detection type

**Next**

4. Confirm whether to **Save** or **Discard changes** to the newly created detection zone.

**Save Detection Zone test?**

Please note: Detection Zones will only impact the controller once they are published.

**Save**      **Discard changes**

5. Repeat steps 1 to 4 to create additional detection zones or optional zone types such as **Counting zone**, **Vulnerable Road User**, **Full approach Zone**, or **Departure Zone**, (see the sections below for details).



6. When all required and optional zones are configured, click **Publish changes** to apply the configuration. Each detection zone created is listed with its configuration settings in the table on the right.

SU Configuration  
McClintock Drive - SB

Sensor aiming   Sensor calibration   Ingress configuration   Approach setup   **Detection zones**   Intersection view   ? Guidance

Mode: Factory

Detection Zones (\*Only published zone will effect controller)

Zone	Name	From SB (ft)	Length (ft)	Vehicles Types	Output Type	Output Number	Condition
A	Phase1_Out14_AllVehicles	0	40	All vehicles	Presence	14 Pulse	No
B	Phase2_Out14_Disabled	108	30	All vehicles	Presence	24	No
C	Phase2_Bicycles	0	48	Bicycles only	Presence	34	No
Count1	Phase2_Out54	-	-	All vehicles	Pulse	52	No
D	Phase2_Ped zone	-10	20	Ped only	Presence	31	No


### 9.5.2 To Create Optional Detection Zones

During **Detection Zone** setup, the following optional configuration features are available:


- **Counting zone** - define per lane, they are used to send pulse signals to the the selected output port on TSC.
- **Vulnerable road user** - used to identify and prioritize protect detection for pedestrians and cyclists.

#### To configure a Counting zone

1. Click **Counting Zone**.



2. Left-click on the required lane.



**Note**

Polygons shown during Counting Zone setup are carried over from previously created Detection Zones.

- You may skip the Detection Zone step and begin directly with the Counting Zone.
- You can still select the lane (colored area) by clicking on it, even if no polygons are present.

3. Fill in the required fields. Click **Next** after completing each field:

- Enter a descriptive name for the **Detection zone name**.
- Select an **Output number**.
- Select the **Vehicle detection type**.


Detection Zones (\*only published zone will effect controller)

**DETECTION ZONE SETUP**

Detection zone name

Output number

Vehicle detection type




4. Confirm whether to save or discard the newly created detection zone.

## To configure a Vulnerable road user (VRU) zone

### Note

Pedestrian detection is an **add-on** feature that requires a separate purchase.


1. Click **Vulnerable road user**.



2. Select the vector points to define the detection zone. The zone will appear superimposed on the selected lane.

### Note

For pedestrian protection (extension), the VRU zone should extend approximately 20 % beyond the crosswalk width, away from the stop bar.



3. Fill in the required fields. Click **Next** after completing each field:
  - a. Enter a descriptive name for the **Detection zone name**.
  - b. Select an **Output number**.
  - c. Select the **Road user** to be detected (e.g. Bicycle, Pedestrian).

**DETECTION ZONE SETUP**

Name the detection zone

Select output number (1-64)

Select output type


Road users should be detected

Next

4. Confirm whether to save or discard the newly created detection zone.

### 9.5.3 To Configure Full Approach Zone

1. Click **Full approach zone**.



#### Note

The **Full approach zone** is configured **only after** the intersection enters **Managed Mode**. It is not included in the Wizard flow.

### 9.5.4 To Create Departure Zones

A departure zone is a zone type that enables detection of road users in the departing lanes of an intersection leg. This feature expands the system's coverage beyond approach-only detection.

#### Prerequisites and limitations

- Make sure the Sensor is positioned to view the entire leg, including the departing side.

### Note

Sensors are typically aimed at the approach only. For Departure Zones, the Sensor must cover the full leg, which could require re-aiming.


- Departing lanes are not mapped as individual lanes in the system. Departure zones are drawn freehand.

## To configure a Departure zone

1. Click **Departure zone**.



2. On the image, draw the zone freehand on the departing part of the leg by clicking four points in the required order (same method used for all detection zone polygons).
3. Review the created departure zone and redraw it if necessary.



## Configuring Departure zone characteristics

After drawing the zone, follow the wizard steps to define the zone properties:

1. **Name the detection zone** – enter a name for the Departure zone.
2. **Introduce output number** – select the output number from the list of available outputs.
3. **Output type:**
  - Default: **Presence**.
  - Optional: Select **Pulse** if required.

#### 4. **Vehicles should be detected** – select the road user type.

- Default: **All vehicles**.
- Optional: Select **Bicycles only** if the zone should trigger exclusively for bicycles.


### Activating the Departure Zone

After completing all wizard steps, a confirmation pop-up appears.

#### 1. Click **Activate** to enable the new departure zone.

The departure zone:

- Appears on the image
- Is added to the detection zone list for the leg with its assigned name, output, and characteristics as follows:




### 9.5.5 Managing Detection Zones


Each detection zone includes detection zone management actions that allow you to modify, disable, restore, or remove detection zones without recreating them.

Available menu options:

- **Recall**
- **Deactivate**
- **Edit**
- **Delete**

## Accessing the Detection Zone management tools

1. Click **Detection Zone** to open the detection zone list on the right side of the screen.
2. Locate the detection zone you want to manage  
and click .




### Recall a Detection Zone

Use recall to restore a previously deactivated detection zone.

1. Select **Recall**.

A notification appears directly on the zone, confirming the recall action. The detection zone becomes active again and resumes normal operation.



### Deactivate a Detection Zone

Deactivate temporarily disables a detection zone without deleting it.

1. Click **Deactivate**.

A notification appears on the zone, indicating that it has been deactivated. The zone remains in the list but is marked as **Deactivated**.



#### Note

Deactivated zones can be restored at any time using the **Recall** action.

## Edit a Detection Zone

Use this option to modify the existing zone shape or update its characteristics.

1. Click **Edit**.

The system switches the zone into edit mode, allowing you to adjust:

- Zone shape (redraw the polygon as required)
- Zone characteristics (e.g., name, road-user type, output number, output type)

2. Click **Next**.

The updated detection zone appears on the image and in the zone list.

## Delete a Detection Zone

Delete permanently removes the zone from the image and from the zone list.

1. Select **Delete**. An **Are you sure?** confirmation pop-up appears.

2. Click **Confirm** to permanently delete the zone.

### Caution

Deleted detection zones cannot be recalled. To use the zone again, you must recreate it from the **Detection Zone** setup page.

## 9.5.6 Apply Detection Zone Configuration


1. When all required and optional zones are configured, click **Publish changes** to apply the configuration. Each detection zone appears in the table on the right, showing its configuration settings.


The screenshot shows the 'SU Configuration' interface for 'McClintock Drive - SB'. The interface includes a navigation bar with steps: Sensor aiming, Sensor calibration, Ingress configuration, Approach setup, and Detection zones (currently active). Below the navigation bar is a street view image with several detection zones marked by numbered circles (1-5) and colored polygons. A table on the right lists the configured detection zones.

Zone	Name	From SB (ft)	Length (ft)	Vehicles Types	Output Type	Output Number	Condition
A	Phase2_Out14_AltVehicles	0	40	All vehicles	Presence	14 Result	No
B	Phase2_Out24_Destructive	108	30	All vehicles	Presence	24	No
C	Phase2_Bicycles	0	48	Bicycles only	Presence	34	No
Count1	Phase2_Out24	-	-	All vehicles	Pulse	52	No
D	Phase2_Ped zone	-10	20	Ped only	Presence	31	No


At the bottom of the interface, there is a 'Publish changes' button.

## 9.6 Assigning the Sensor to the Intersection


1. Navigate to the **Intersection View** for the Sensors and make sure that the status of all configuration steps is successfully completed. This is indicated by five  in the lower right section of the Sensor screen view.




2. Click **Assign Sensor Unit**.



3. Click **Continue**.




4. Wait while the unit is being assigned.




5. Either of the following options result:

- **Passed** – click **Continue**. The IM moves the Sensor status to **Mode: Operational**.



- **Failed** – click **Back**. If the problem persists, contact the NOC, see [Appendix D - Support](#).



## 9.7 Complete Set Up of all Sensors

1. Repeat steps [9.1](#) to [9.6](#) to configure all remaining Sensors at the intersection.
2. Make sure the status of all Sensors in the intersection is Mode: Operational, click **Complete Setup**.



Once all Sensors are assigned and their status is **Mode: Operational**, the intersection can then be finalized and moved to operational status. This requires running final system tests and registering the intersection location.

### Note

You can complete the setup of the intersection even if an Sensor has failed.

## 10. System Tests

1. In line 1 select whether a Sensor Power Unit is included in the installation.

System Tests	
1	Do Sensor Power Unit exist in this installation? <span>No ▾</span>
2	Repeaters <span>0 ▾</span>
3	TLS status <span>No ▾</span>
4	Presence of detection zones for each SU
5	Detection status
6	Communication between units
7	LTE communication
8	SUs remote connectivity
9	Nexus remote connectivity

Run tests Request registration

2. In line 2 select the number of repeaters.
3. In line 3 confirm the TLS Status.
4. Click **Run Tests**.
5. Once all system tests have passed, click **Request registration**.

System Tests	
✓	Do Sensor Power Unit exist in this installation? <span>Yes ▾</span>
✓	Repeaters <span>1 ▾</span>
✓	TLS status <span>No ▾</span>
✓	Presence of detection zones for each SU <span>Passed</span>
✓	Detection status <span>Passed</span>
✓	Communication between units <span>Passed</span>
✓	LTE communication <span>Passed</span>
✓	SUs remote connectivity <span>Passed</span>
✓	Nexus remote connectivity <span>Passed</span>

Run tests Request registration

6. If a system test fails, select the test name of the failed test.

7. Click **Run Test**.

**System Tests**

✗ Do Sensor Power Unit exist in this installation?	Yes ▾
✗ Repeaters	1 ▾
✓ TLS status	No ▾
✓ Presence of detection zones for each SU	Passed
✗ Detection status	Failed
✗ Communication between units	Failed
✓ LTE communication	Passed
✓ SUs remote connectivity	Passed
✓ Nexus remote connectivity	Passed

**Sensor Power Unit**  
Assess communication for Sensor Power Unit.

**Troubleshooting**

- Make sure the sensor power unit is powered on, including the front switches (Where Sensors are connected)
- Make sure the data cable between nexus and sensor power unit is connected

If issue persists, contact NoTraffic support (US and Canada):  
 Email: [support@notraffic.tech](mailto:support@notraffic.tech)  
 Toll-free: 1-888-771-7879  
 Direct: 1-202-800-1890

Run Test    Request registration


A window appears with the description of what to test along with troubleshooting recommendations. If the problem persists, contact the NOC using the details provided, see [Appendix D - Support](#).

**Note**

You can proceed to register with the NOC even if some tests have failed.

## 11. Registering the Intersection

1. Select the check box to accept the conditions for registering the intersection.



The screenshot shows a dialog box titled "You're almost there!" with a close button (X) in the top right corner. The dialog contains the following information:

- Intersection name:** McClintock Drive & Main Street
- Number of Sensor Units: 4**
  1. N McClintock Drive - NB
  2. N McClintock Drive - SB
  3. W McClintock Drive - WB (Type 2)
  4. W McClintock Drive - EB

Below the list, there is a checkbox and a warning message: "Clicking **Register Intersection** will complete the installation process and trigger the next phase, which will be handled by our NOC team. After this step, you will no longer be able to use NT guest." At the bottom, there are two buttons: "Register Intersection" (highlighted in blue) and "Go Back".

2. Click Register Intersection.

### Note


If registration of the intersection failed, contact the NOC, see [Appendix D - Support](#), to resolve the issue.

### Note


Once an intersection is successfully registered and transitioned to Managed Mode, the NOC monitors its performance and finalizes the configuration needed for the radar to operate effectively.

3. The intersection is successfully registered.

- You can close the laptop or click **SU Configuration** or **Detection Configuration** to verify your current communication configuration settings.



- The intersection is reviewed by the NOC and once approved the IM status of the intersection and all Sensors change to **Mode: Managed**.



**Note**

Any future changes to the configuration must be coordinated with the NOC team.

## 12. Downloading Traffic Movement Counts (TMC)

Using the TMC feature, you can directly download movement count data, giving agencies automated access even if service agreements are not renewed after five years.

TMC data is exported in CSV format, with feature capabilities as follows:


- Up to 30 days of TMC data retained
- Retrieval window: up to 24 hours per download
- Near real-time data: latest movement counts available
- Fixed 15-minute aggregation interval

### Data Schema (CSV Fields)

Field	Description
Unit ID	Unique identifier of the sensor
Unit Name	Intersection-specific sensor name
Movement Type	Type of movement (e.g., right turn, through, left turn)
Timestamp	Recorded time of event (UTC)
Road User Type	Classification (e.g., passenger vehicle, truck)
Number of Movements	Total count for the defined interval


## Downloading TMC Data

1. Navigate to the **Intersection View** for the Sensors.
2. Click **Download Counts**.



3. A pop-up window appears. Select the date and time range for the TMC data you want to retrieve.
  - The maximum retrieval range is 24 hours per download.

### Traffic Counts



4. Click **DOWNLOAD**.

IM generates a CSV file containing the Traffic Movement Counts for the selected time range.

## CSV Output Example

Movement counts are provided per sensor and per movement.

- All timestamps are provided in UTC.
- Movement types follow NoTraffic's standard movement definitions (e.g., TH, LT, RT).

### Example — Northbound Movement Counts (Separate for Both Sensors)

unit_id	unit_name	movement_type	timestamp	road_user_type	number_of_movements
22	SH6-NB	NBRT	2024-07-03T00:00:00Z	Passenger Vehicle	105
22	SH6-NB	NBTH	2024-07-03T00:00:00Z	Passenger Vehicle	447
24	SH6-NB-Inner	NBLT	2024-07-03T00:00:00Z	Passenger Vehicle	149
24	SH6-NB-Inner	NBTH	2024-07-03T00:00:00Z	Passenger Vehicle	401

### Example — Southbound Movement Counts (Separate for Both Sensors)


unit_id	unit_name	movement_type	timestamp	road_user_type	number_of_movements
23	SH6-SB	SBRT	2024-07-03T00:00:00Z	Passenger Vehicle	45
23	SH6-SB	SBTH	2024-07-03T00:00:00Z	Passenger Vehicle	446
25	SH6-SB-Inner	SBLT	2024-07-03T00:00:00Z	Passenger Vehicle	148
25	SH6-SB-Inner	SBTH	2024-07-03T00:00:00Z	Passenger Vehicle	461

## 13. Troubleshooting

### 13.1 No BIUs Available

When no BIUs are available (none are green) resolve as follows assuming at least one is gray. The following example is from the Cobalt controller; other controllers have different screens.

1. Open **MAIN MENU** on the controller unit.
2. Select **SUB-MENU** number 1.
3. Select **SUB-MENU** number 4.
4. Select **SDLC OPTIONS** for an available BIU as indicated by an **X** under a BIU number.




## 13.2 Detection Failure


### Resolve the detection failure as follows:

1. Open **MAIN MENU** on the controller unit.
2. Select **SUBMENU** number 7.
3. Select **DETECTORS** number 6.


#### 1. OPEN MAIN MENU



#### 2. CHOOSE STATUS SUB-MENU (7)




#### 3. CHOOSE DETECTORS (6)



### 13.3 Frame Detection Stops

If the frame counter stops or no frames are received during simulation of detection, the following error message displays:



Check the cable connection or click **Skip for now** to skip this step.

### 13.4 Flashing the Smart Harness

In certain situations, the Smart Harness may require a firmware (FW) update. This can occur automatically or may require manual intervention.

#### Automatic Firmware Update

If the Smart Harness FW is outdated, the system automatically triggers a FW update when the Nexus Omni detects the Smart Harness. A pop-up message appears on-screen, prompting you to proceed with the update.

No user action is required unless the automatic update fails.

#### Manual Flashing of the Smart Harness

If detection issues persist and all other diagnostics have passed successfully, a manual Smart Harness firmware flash may be required.

#### To manually flash the Smart Harness firmware

1. Click **Troubleshooting** from the Detection screen and verify all troubleshooting checks have been completed.
2. Click **Proceed to Flash Smart Harness**.

### Troubleshooting

- 1 Check all connections and inspect for faulty or damaged cables.
- 2 Verify power to the Smart Harness and ensure that the power LED is illuminated.
- 3 If all the above checks pass, proceed to reflash the Smart Harness.

Proceed to Flash Smart Harness

3. Select the **Smart Harness type** from the dropdown list.
4. Select the **Port** to which the Smart Harness is connected on the Nexus Omni.
5. Click **Flash Smart Harness**.

BIU
Detection
Troubleshooting

### Flash Smart Harness

Please provide the required parameters below before initiating the flash.

Smart Harness Type
▼

Port Selection
▼

Flash Smart Harness

6. A progress bar and then confirmation message appears once flashing is complete.

### Flash Smart Harness

Flashing in process ...

Smart Harness Type  
SDLC

Port Selection  
1

### Flash Smart Harness

✔ Flashing Smart harness - Succeed!


## Appendix A. BIU Communication and Configuration

The BIU communicates between detectors and the master controller. It requests the status of detectors 1-16 or up to 24 for SIU. The BIU must respond immediately, failure to do so results in the BIU entering a "fault" state. Proper configuration and enabling of a BIU are essential for accurate status reporting and avoiding bus congestion, which can arise if multiple BIUs respond simultaneously. Congestion increases the number of bad frames and in severe cases may cause the controller to switch to flash mode. The controller queries the status of all BIUs that are enabled in the controller program. Only enabled BIUs are queried.

## Appendix B. Warning Messages

### B.1 TLS Selection Warning


If another TLS connection method is set up, click **Continue** to switch to the new connection type. Alternatively click **Go Back** to cancel the setting up of the communication type selected and select a different type.



## Appendix C. Regular and Diamond Intersections


- **Regular** (non-diamond) intersection

In the following example each Sensor has a unique **Sensor name – Main Street 1** and **Main Street 2**. Neither Sensor is selected as Inner.



- **Diamond** Intersection

In the following example each Sensor has the same **Sensor name – Main Street**. One is selected as **Inner** (marked blue), and the other is not.



## Appendix D. Support

Technical support for troubleshooting is available 24/7/365 by phone or email. Certain restrictions and exclusions may apply.

Contact the support number 3 days in advance of aiming new Sensors or renaming existing Sensors.

### Contact Support (U.S. and Canada)

- Email: [support@notraffic.tech](mailto:support@notraffic.tech)
- Toll-Free: 1-888-771-7879
- Direct: 1-202-800-1890

## Appendix E. Troubleshooting

This section tables operational case scenarios and lists the steps to take to resolve each case.

Scenario	Nexus Omni Switches From Factory To Operational Mode	Sensor Switches From Factory To Operational Mode	System Tests Status	Intersection Switches From Factory To Operational Mode
Scenario 1	✓	✓	✓	✓
Scenario 2	✗	NA	NA	NA
Scenario 3	✓	✗	✓ and/or ✗	✗
Scenario 4	✓	✓	✗	✗

### E.1 Scenario 1 – Successful Process Completion

- The Nexus Omni switches from Factory mode to Operational mode after setting up the City Network.
- The Sensors switch from Factory mode to Operational mode after successfully assigning them to the intersection.
- All system tests have run successfully.
- The intersection automatically switches to Operational mode.
- Click Register Intersection.
  - The registration request is sent to the NOC.
- The NOC moves the intersection and all units to Managed mode.

### E.2 Scenario 2 – Problems

- The Nexus Omni failed to switch from Factory to Operational mode.
- The installation is blocked.
- Retry and/or contact the NOC.

### E.3 Scenario 3 – Problems

The Nexus Omni switches from Factory mode to Operational mode after setting up the City Network.

- At least one Sensor failed to switch to Operational mode after assigning to the intersection.
- All system tests have run, regardless of success or failure.

In this case, there are two options:

- Contact the NOC team to attempt remote troubleshooting (accessing the intersection manager remotely).
- Continue to register the faulty intersection (proceed to steps 4-7).

#### **If the installer decides to continue with the registration process:**

- Click **Register Intersection**. The intersection remains in Factory mode.
- The NOC team:
  - Fixes the errors in the Sensors.
  - Assigns Sensors again till successful.
  - Runs the system test.
- The intersection switches to Operational mode
- The NOC moves the intersection and all units to Managed mode.

### E.4 Scenario 4 – Problems

- The Nexus Omni switches from Factory mode to Operational mode after setting up the City Network.
- The Sensors switch from Factory mode to Operational mode after successfully assigning them to the intersection.
- The system tests failed.

In this case, there are two options:

- Contact the NOC team to attempt remote troubleshooting (accessing the intersection manager remotely).
- Continue to register the faulty intersection (proceed to steps 4-7).

**If the installer decides to continue with the registration process:**

1. Click **Register Intersection**. The intersection remains in Factory mode.
2. The NOC team:
  - Fixes the errors in the System tests.
  - Runs the system test until successful.
3. The intersection switches to Operational mode
4. The NOC moves the intersection and all units to Managed mode.